




INSTALLATION: SCHEMATIC DRAWINGS




1. Drill the holes in the aluminium bar.



2. Fix the aluminium bar to the wall or ceiling using the appropriate plugs and screws according to the surface base. Then, attach the panel down to connect with the aluminium bar.



3. Fix the aluminium side bar in order to retain the panel until the next step. Slide it to the side in order to connect the next panel.



4. Repeat the parts 2 and 3 until you get the desired result. Any panel can be cutted depending on the walls and ceiling dimensions.

INSTALLATION: EXAMPLE IMAGES



IMPORTANT NOTICES

- JOCAVI® accepts no responsibility for any printing errors. Specifications can be modified without prior notice, if technical or commercial reasons so require.
- The colours shown on this catalogue are only a reference and an illustration of the products finishing. The colours shown are not binding because brightness, contrast and colour balance may vary due to the printing process.
- Colours may vary due to raw-material suppliers' changes and some differences may occur in tonal range.
- Due to its natural origin, wood-based products will always present natural imperfections inherent to the organic nature. And for similar reasons, they will also present traces of old-age in the course of time.
- Wood and Fabric products are highly susceptible to change its appearance with humidity and temperature. Close attention must be paid to the storage conditions and the acclimatization before, during and after the installation.
- Typical Indoor Comfort Standards state a temperature range of 20°C - 27°C (68°F - 81°F), and a relative humidity of less than 60%. These would be considered as normal operational levels of JOCAVI® products' range.
- Despite all the standard sizes of all products, this model can be customised upon previous consultation. Sizes may vary slightly due to their production method and some inherent raw-materials characteristics.